



NARAS

Smart Seeder Agritech

WITH THE NEW GENERATION, HIGH-TECH SENSORS AND ELECTRONIC EQUIPMENT, YOU CAN INSTANTLY MONITOR THE DETAILED DATA READ FROM THE SEED DRILL VIA THE TOUCH USER SCREEN, TRACK THE SOWN AREAS WITH MAPPING AND EASILY CONTROL THE MACHINE.

The amount of seeds to be sown is adjusted precisely by the software using the vehicle speed calculated by the data received from satellite signal. At the beginning and end of the rows, sowing is started and stopped automatically, markers are also automatically lift down and lift up by the software control without need user intervention. Thanks to the sensors located on the system, seed level, seeding speed, amount of seeds planted, planted decares, fan status and operation time can be monitored instantly by the user.



Automatic Tracking System

Adjust Seed Amount Automatically



Monitor Sown Seed

Avoid Overlapped Seeding



CENTER OFFICE

Kazım Dirik Mah. 296/2. No:33 Bornova,
İzmir/Türkiye
T: +90 232 700 22 94

info@narasmakina.com

EXHIBITION AND STORAGE CENTER

Fevzi Çakmak Mah. Gülistan Cad. No:11
Karatay/Konya
T: +90 332 503 11 44



+90 535 717 54 56